


BWOO[®]



BASS WIRELESS SPEAKER

BS75




A. Tunebuds will automatically enter pairing mode. Turn on bluetooth on the mobile phone, click search for the device Choose “BS75” to connect.


Note: When BS75 and mobile phone are disconnected due to distance, Tunebuds will automatically attempt to reconnect for 3 minutes



10M








Directions for use



1		On/Off button	Press and hold to switch the device on or off
2		Mode button	Press to select Radio / Bluetooth / Aux mode
3		Volume Down / Previous button	Press to decrease the volume In Bluetooth mode: Press and hold to select the previous song
4		Snooze button	When alarm rings, press to delay the alarm for 5 minutes
5		Volume Up / Next button	Press to increase the volume In Bluetooth mode: Press and hold the button to select the next song
6		Play/ Pause button Bluetooth button Hands-free Call button	Press to play or pause the song Press and hold to disconnect bluetooth In Bluetooth mode: <ul style="list-style-type: none"> ● Press to answer incoming call, press the button again to end the call. ● Press and hold to refuse an incoming call
7		Alarm button	Press to display the clock and alarm



Directions for use





8		AUX input (3.5mm)	Plug AUX cable to the AUX input and connect the audio source
9		Micro USB port	Micro USB charging port
10		LED Indicator	Charging indicator
11		LED Display	<ul style="list-style-type: none"> ● Time and alarm display ● Radio Mode: FM Frequency display ● Bluetooth Mode: BLUE ● Aux Mode: LINE

CHARGING

Note: Please use the original charger wire to charge the headset. Do not use fast charging to avoid damage or reduce the service life of the headset.



BOX OVERVIEW



BWOO[®]

<https://bwoohk.com>

<https://bwoohk.com>